


Шаг 1. Определите угол и высоту для подвешивания сетки. Просверлите в одной из стен близко к углу отверстие диаметром 5 мм. Вставьте один из дюбелей в отверстие и вкрутите металлический крючок. Навесьте угловой конец сетки на крючок.

Шаг 2. Расправьте и натяните сетку, после чего отметьте места для отверстий боковых крючков. Примечание: Для лучшего результата рекомендуется понизить высоту отверстий боковых крючков на 8-10 см относительно углового крючка.

Шаг 3. Аналогично шагу 1 просверлите боковое отверстие, вставьте дюбель и вкрутите крючок. Навесьте конец сетки на крючок.

Шаг 4. Повторите шаг 3 для противоположной стороны. Сетка готова к использованию.



1. Determine corner location, height and position of net. Drill a 3/16" (0.48 cm) diameter hole. Push one of the plastic anchors provided into the hole and screw in one of the metal hooks. Hang back corner of net.
2. Extend each side outward until tight and mark the location for the two remaining hooks. **NOTE:** For best results, after locating position points for side hooks, lower the points 3-4" (7.62-10.16 cm).
3. Starting with one of the side hook location marks, drill 3/16" (0.48 cm) diameter hole, insert plastic anchor and screw hook into anchor. Hang one end ring over hook.
4. Repeat step 3 for other side hook. Toy net is ready to use.

**CARE:** Machine wash warm. Tumble dry low. Do not iron.

WHITMOR, INC.  
210335\_001-3/16  
GUANGDONG, CHINA



**WARNING!**

**Choking hazard! Small parts!  
Adult assembly required!**

Do not store heavy items on toy net. Do not allow children to hang from or climb into the toy net. As a safety precaution, do not place net over sleeping areas.

**ВАЖНО!**

**НЕ ХРАНИТЕ ТЯЖЕЛЫЕ ПРЕДМЕТЫ В СЕТКЕ.**

**НЕ ПОЗВОЛЯЙТЕ ДЕТЯМ ЗАБИРАТЬСЯ В СЕТКУ ИЛИ ВИСНУТЬ НА НЕЙ.**

**НЕ РАЗМЕЩАЙТЕ СЕТКУ НАД КРОВАТЬЮ РЕБЕНКА.**

MADE IN CHINA  
©2016 Whitmor, Inc.  
8680 Swinnea Road • Suite 103  
Southaven, MS • 38671  
1-888-WHITMOR  
help@whitmor.com  
www.whitmor.com